

puroair

PUROAIR 240 AIR PURIFIER
USER MANUAL

TABLE OF CONTENTS

| | |
|---------------------------|----------|
| Safety precautions | 4 |
|---------------------------|----------|

| | |
|---|----|
| Product information | 6 |
| Control panel | 7 |
| Removal of base cover | 8 |
| Placement of air purifier | 9 |
| Setup for first use | 10 |
| Understand the role of filters | 12 |
| 3 stage filter | 14 |
| Turning on the purifier and auto mode | 17 |
| Manual & automatic mode | 10 |
| Fan speed, timer, sleep mode and filter reset | 18 |
| Child lock function | 19 |
| Maintenance | 20 |
| Troubleshooting | 22 |



puroair

SAFETY PRECAUTIONS

In order to avoid possible injury or financial loss to you or others, please pay attention to the following safety precautions.

If the power cord is damaged, do not attempt to repair it at home.

WARNING



Do not touch power plug with wet hands.



Before cleaning the purifier, make sure that the power supply has been disconnected.



Only 120V ~AC power supply should be used.



Fully plug in the air purifier before turning on.

If the plug is not fully inserted into the socket, it may cause electric shock or overheating.

Do not use damaged plugs or loose power outlets.



Do not damage the power cord and socket.

When using the purifier, do not bind the wires. Using damaged wires may lead to electric shock, short circuit or fire.

Do not cut, twist, poke and pull wires, or place heavy objects on wires or sockets.



Please clean the power plug regularly.

Pull out the power plug and clean it with a dry cloth (do not use a wet cloth).

If the appliance is not used for a long time, the power plug should be removed.



- If you need to move the product, please disconnect the power first.
- Be sure to move the product slowly.
- Do not move the product by pulling the power cord.
- Do not move the machine while the product is in operation. If you need to move the machine, please turn off the power.



Do not use if:

- If a switch does not work.
- If the power cord or plug is abnormally hot.
- If the fuse burns out.
- If you notice a burnt odor or abnormal sound or vibration.
- If there is any other abnormal phenomenon or fault.

WARNING



Do not disassemble or refit the air purifier without authorization.



Do not place rods or metal objects near or in the air outlet or opening.



Do not use benzene, thinner or other solvents to clean the air purifier.



Do not use this air purifier in a place with a high temperature, high humidity or a wet environment such as a bathroom.



Do not use the air purifier in a room with fumigation insecticides.

Chemical residues may accumulate in the unit and then be released from the air outlet which can be dangerous.




After using insecticide, the room should be thoroughly ventilated before using the air purifier.




Do not let volatile substances or combustible materials, such as tobacco and sparks, float into the purifier.

PRODUCT INFORMATION

ANATOMY




CONTROL PANEL KEY



REMOVAL OF BASE COVER


Remove the base

Twist handle to remove base cover from the unit.



Re-install base

To re-install the base, press the unlock key to align and screw it in the locking direction.




OPTIMAL PLACEMENT OF AIR PURIFIER

In order to achieve optimal air circulation and filtration, make sure the air intake and output of the machine are more than 8 inches away from any obstacles.

Please keep the air purifier 3 ft away from other electrical appliances.

Please do not plug the power into the same socket as another electrical appliance.


Do not obstruct the air intake or output to ensure adequate ventilation and maximum efficiency.



REMOVING FILTER PACKAGING FOR FIRST USE


Step 1

Remove all packaging materials and place the machine on a dry, stable, level surface.




Step 2

Unscrew the base cover on the bottom of the purifier by twisting it counter clockwise.




Step 3

Remove the filter from inside the purifier.




Step 4

Remove the packing material from around the filter.




Step 5

Place the filter back into the purifier, with the white handle facing up.




Step 6

Screw in the base cover until it is tight.





UNDERSTANDING THE ROLE OF FILTERS

Clean, filtered air flows out of the top of the purifier.



Polluted air enters through the 360 intake.




Polluted air enters through the air intake and is pushed through the filter which removes pollutants and flows through the air output on top of the purifier.



Only use genuine PuroAir HEPA 14 filters with this purifier. Alternative filters can cause operational issues and will void the 2-year warranty.



UNIQUE TRIPLE PURIFICATION TECHNOLOGY



Prefilter
Screen



High Efficiency
HEPA 14 Filter



High Efficiency
Activated Carbon



puroair



IMPORTANT FUNCTIONS

Turning on the purifier



Press the power button to power on the purifier. The machine will enter auto mode and the automatic light will illuminate and the air quality indicator will display as orange while the purifier calibrates. After a 10-20 second calibration, the air quality indicator will be displayed based on the quality of the air surrounding the unit. When the purifier is running in auto mode, the fan speed will be selected automatically based on the air quality detected.

To turn off the product, press the power button again or unplug the purifier from the outlet.

Manual mode + automatic mode



Manual mode

After powering on, the air purifier is in standby mode. Press the power button to start the air purifier. To enter auto mode, press the fan speed adjustment button (labelled “auto/mode”). To manually set the fan speed, press the auto/mode button again until the unit reaches the fan speed as desired. If you continue to press this button, it will cycle through low, medium, high, and sleep. After adjusting the fan speed, the product runs continually at that speed.

Auto mode

When in auto mode, the purifier will automatically adjust the fan speed and air quality indicator light based on the quality of air surrounding the unit.


| Color | Air Quality | Fan Speed |
|-------|--|-----------|
| ● | Acceptable | Low |
| ● | Moderate (Some pollutants detected) | Medium |
| ● | Poor (High level of pollutants) | High |

Fan



To enter auto mode, press the fan speed adjustment button (labeled “auto/mode”). To manually set the fan speed, press the auto/mode button again until the unit reaches the fan speed as desired.

Timer setting



To run the purifier for a specific amount of time, select the timer button. The purifier can be selected in 2 hours, 4 hours, 6 hours or 8 hours.

Sleep function



When the product is running, press the fan speed button until the sleep indicator is illuminated. When in sleep mode, the fan will run at a low speed, and other indicators will be off.

Reset function



When the replace filter light is illuminated, the current filter needs to be replaced with a new one. Filters can be found at getpuroair.com.

After the filter is replaced, press the “replace filter” button for 5-10 seconds. This will reset the filter sensor.

Child lock



HOLD TO LOCK

Child lock prevents any other functions from being used. To enable child lock, press and hold the lock button for 5 seconds. The lock will illuminate and all functions will be locked. If any other button is pressed, the lock indicator will flash 3 times.

To disable child lock, press and hold the child lock button for 5 seconds and all functions will return to normal.



MAINTENANCE & CLEANING



- Unplug the power plug before cleaning the product.
- Do not immerse the product in water or any other liquid.
- Do not use abrasives or corrosive cleaning agents.
- The filter is not washable.

Clean air purifier

Clean the inside and outside of the purifier body regularly to prevent dust accumulation.

- Use a soft dry cloth to wipe the dust off the purifier.
- Clean the air intake and output with a soft dry cloth.



TROUBLESHOOTING

Problem?

Our Phoenix based team is here to help.

Email us at help@getpuroair.com!



| State | Possible causes | Possible solution |
|--|---|---|
| Machine won't turn on | The power plug is not in place | Pull out the power plug and plug in the power again |
| | The power plug or wire is damaged | Contact us at help@getpuroair.com |
| Fan is not working | The machine is not on | Plug in the power and turn on the machine again |
| | The motor is damaged | Contact us at help@getpuroair.com |
| | Motor loose or foreign particles inside the machine | Contact us at help@getpuroair.com |
| Poor purification performance or suboptimal purification capacity | The filter was not replaced | Replace with a new filter (you can find filters at getpuroair.com) |
| | The air inlet or outlet of the machine is blocked | Contact customer service center or dealer |
| | The plastic package of the filter is not removed | Remove the plastic package of the filter screen for reuse |
| | There is not proper clearance or space around the machine to ventilate it | Make sure that the air inlet and outlet of the machine are not less than 3 feet away from the obstacles |
| | There is no filter in the machine | Make sure that the filters are placed in the machine in the order indicated |
| | More than expected room coverage | Recheck whether the area of the used room is consistent with the specified area of the purifier |

For filter replacements and new purifiers visit:

getpuroair.com

Questions? Problems?

Our team in Phoenix, AZ is standing by!

help@getpuroair.com

